


OVEN PARTS
For Models:RBS305PDB10, RBS305PDQ10, RBS305PDZ10, RBS305PDT10
(Black) (Designer White) (Designer Almond) (Biscuit)

NOTE: The screws and nuts required to attach a part are listed immediately following that part.
4450646 Write Model 4450849 Almond Model 4452121 Biscuit Model 4449041 Screw  25 4454691 Side, Chassis (R.H. & L.H.) 4449809 Screw  4449316 Insulation, Wrap 4450365 Insulation, Back

## **OVEN DOOR PARTS**

For Models:RBS305PDB10, RBS305PDQ10, RBS305PDZ10, RBS305PDT10 (Black) (Designer White) (Designer Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4452066 White Model

4452067 Almond Model 4452859 Biscuit Model 24


4455257 Glass, Inner


8185617 3

4449263 Glass, Inner

# **INTERNAL OVEN PARTS**

For Models:RBS305PDB10, RBS305PDQ10, RBS305PDZ10, RBS305PDT10 (Black) (Designer White) (Designer Almond) (Biscuit)






Illus. Part No. No.		DESCRIPTION				
2	4452154	Element, Broil				
	4449154	Screw				
3	3147563	Grill, Broiler				
4	3147845	Pan, Broiler				
6	4448717	Rack, Oven				
7	4452153	Element, Bake				
	4449154	Screw				

# **CONTROL PANEL PARTS**

For Models:RBS305PDB10, RBS305PDQ10, RBS305PDZ10, RBS305PDT10 (Black) (Designer White) (Designer Almond) (Biscuit)




Illus. Part

No. No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Control Panel Assy. W/Membrane Switch
	8300450	Black Model
	8300449	White Model
	8300448	Almond Model
	8300535	Biscuit Model
	8281179	Screw
2	4451034	Gasket,
		Control Panel
3	4453193	Microcomputer
	4449745	Screw

TOP VENTING PARTS
For Models:RBS305PDB10, RBS305PDQ10, RBS305PDZ10, RBS305PDT10
(Black) (Designer White) (Designer Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
require listed i that pa	ed to attammediat art. 4451759	rews and nuts ach a part are tely following  Vent, Exhaust Screw Elbow, Vent-Top	3 4 5 11 13	4451758 4455177	Bracket, Blower Block, Foam Elbow, Vent-Bottom Block, Terminal Screw Vent, (Control Panel)	14 15 16 18	4449809 4450551 4449809	Left Screw Back, Control Screw Cover, Top Rear Screw Cover, Top Front

8185617

OPTIONAL PARTS
For Models:RBS305PDB10, RBS305PDQ10, RBS305PDZ10, RBS305PDT10
(Black) (Designer White) (Designer Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION		Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION		
PAINT	No. 7, TOUC 72017 261869 72032 T, SPRA 350930 261900 830864	H-UP (1/2oz.)  White Cord Brown Black  AY  White Citrine White	No. SPLICING LENGTH  2 2 2 2 2	No. G WIRE 242828 242820 242821 242822 242830	Wire (12 Ga. 150 c Black) Wire (14 Ga. 150 c Black) Wire (14 Ga. 150 c Blue) Wire (14 Ga. 150 c Blue) Wire (14 Ga. 200 c Brown) Wire (14 Ga. 200 c Brown) Wire (14 Ga.	No. WIRI	No. No. DESCRIPTION  WIRING HARNESS PARTS  4455733 Harness, Wire (Main) 4450952 Conduit 4448664 Clamp 4449809 Screw 112432 Nut 4450800 Screw, Ground 4451761 Support, Wiring 4454842 Tie, Cable 4452222 Spacer, Harness			
		Adhesive Loctite (1/3 oz.) Sealer, Silastic (3 oz.)	2 2 2 2 2 2	242824 242829 242825 242831 242826 242827	150 c Green) Wire (14 Ga. 150 c Orange) Wire (12 Ga. 150 c Red) Wire (14 Ga. 150 c Red) Wire (14 Ga. 200 c Red) Wire (14 Ga. 150 c White) Wire (14 Ga. 150 c Yellow) Wire (14 Ga. 200 c Yellow)		Pin Hinge Kit Screw, Install (4)			